

Components		Screws
100 Plate	5105	Barrel bridge (cheesehead, polished)
105 Barrel bridge	5110	Train wheel bridge (cheesehead, polished)
110 Train wheel bridge	5121	Balance cock (cheesehead, polished)
121 Balance cock	5125	Pallet cock, (cheesehead, polished)
125 Pallet cock	5311	Top balance endpiece (countersunk, polished ends)
180 Barrel complete with arbor	5330	Bottom balance endpiece (countersunk, polished ends)
182 Barrel and cover	5415	Barrel ratchet
185 Barrel	5420	Top crown wheel (transmission wheel)(lefthand)
190 Barrel cover	5425	Click
195 Barrel arbor	5443	Setting bolt (pull-out piece)
201 Centre wheel complete	5445	Setting bolt spring (pull-out piece spring)
210 Third wheel complete	5721	Balance
220 Fourth wheel complete	5738	Hairspring stud
240 Cannon pinion	5750	Dial edge
250 Hour wheel		
260 Minute wheel		
301 Regulator index		
311 Top balance endpiece		
330 Bottom balance endpiece		
401 Winding stem		
407 Castle wheel		
410 Winding pinion (crown wheel)		
415 Barrel ratchet		
420 Top crown wheel (transmission wheel)		
422 Crown wheel collar		
425 Click		
430 Click spring	630	Top balance
435 Return bar	631	Bottom balance
440 Return bar spring	615	Escape top
443 Setting bolt (pull-out piece)	616	Escape bottom
445 Setting bolt spring (pull-out piece spring)	620	Top pallet
450 Intermediate wheel	621	Bottom pallet
705 Escape wheel complete	646	Entry pallet
710 Pallets complete	647	Exit pallet
721 Balance complete	610	Top fourth
723 Balance staff	611	Bottom fourth
730 Roller	605	Top third
734 Hairspring complete	606	Bottom third
738 Hairspring stud	601	Top centre
770 Mainspring	602	Bottom centre
	648	Roller (impulse pin)

Jewels




Plate I: 5 1/4 x 8 3/4 ligne 15-jewel lever movement (see facing page).